



GENERAL NOTES:

1. THE CONTRACTOR MUST VERIFY ALL DIMENSIONS, INCLUDING EXPANSION JOINT LENGTHS, TO INSURE ACCURACY PRIOR TO FABRICATION AND SHIPMENT.
2. THE CONTRACTOR SHALL FIELD CUT AND/OR MITER EXPANSION JOINTS TO ACHIEVE A PROPER FIT.
3. EXPANSION JOINTS SHALL BE BOXED OR BANDED TOGETHER FOR SHIPMENT. THE MANUFACTURER SHALL TAKE REASONABLE CARE TO PROTECT THE EXPANSION JOINT FROM DAMAGE DURING SHIPPING.
4. STANDARD LENGTHS FOR EXTRUSIONS AND COVER PLATES IS 10'-0" (3048 mm).

QWE-1200 DETAIL
WALL-TO-WALL EXTERIOR APPLICATION

() - Denotes Millimeters

DIMENSION CHART					
MODEL	"A" at Min.	"A" at Mid.	"A" at Max.	System Width	Total Movement
QWE-1200	4"(102)	12"(305)	20"(508)	20 1/8"(511)	16"(406)

Note: Minimum and Maximum Values are after movement occurs. Mid Point Value is the recommended size of the opening at installation.

PROJECT NAME: -

PROJECT LOCATION: -

DRAWING DESCRIPTION:
Wabo®QuakeWall System

DATE: 11/07/2017

MODEL: QWE



Watson Bowman Acme Corp.
95 Pineview Drive Amherst, NY 14228
phone: (716) 691-7566 fax: (716) 691-9239
www.wbacorp.com



Information provided herein, including but not limited to, any drawing, design, photograph, graphic, or statement(s) ("Materials") are proprietary and the property of Watson Bowman Acme Corporation ("Company"). Reproduction, translation, or reduction to any electronic medium or machine readable form, in whole or part, is strictly prohibited, except for the express purpose for which it has been furnished, without prior written consent of Company. All Materials contained herein are provided by Company for information purposes only. Company reserves the right to amend or withdraw any information contained in the Materials without notice. All technical or other advice by Company, whether verbal or written, concerning products, or the use of products in specific situations ("Advice") is given by Company and is used at the Users own risk.

REVISION NO:
-

SHEET NO:
1

DRAWING NO:
34445